

Influence Factors to Pipe Pressure on Cast-in Place Pile Pouring

L Yu*, Z L Liu and G Q Zhang

Beijing Xin-Qiao Technology Development Co., LTD, China

Corresponding author and e-mail: L Yu, yuleimabel@163.com

Abstract. Transducer can be used to detect the interface between concrete and slurry by detecting pressure along pipe. This interface is important to avoid pipe pulled out of concrete and good for cast-in place pile construction. But a lot of factors can affect the pressures on pipe. In order to detect pressure change around pipe and find out the reasons leading to pipe pressure changed, some factors such as density, pouring velocity, concrete temperature and concrete slump must be considered. By means of simulate cast-in place pile construction in library, pressure along pipe were detected. Results shows that density and pouring velocity are the main factors that can be effected on pipe pressure. Concrete temperature and slump are not outstanding factors. From differential pressure curve, interface position between concrete and air can be found.

1. Introduction

During cast-in place pile construction, pipe is used to pouring concrete into pile hole. The interface of concrete and slurry is very important. Pressures are different between concrete and slurry. Transducers can be used to detect this interface by test pressure along pipe. But pressure around pipe will be affected by different factors. To avoid pressure detecting disturbed and get rid of invalid data, these factors should be found out. Refer to concrete form, the pressure around pipe may be affected by pouring velocity, depth, density and temperature. In order to detect pressure change around pipe and find out the interface of concrete and air, these factors must be considered.

2. Test equipment

Laboratory test was done to simulate pouring. A pipe was used to simulate pile hole. Two transducers were tied on a steel stick. Put the stick into pipe and pouring concrete into pipe, the pressure will be detected by transducers on stick. Test equipment is shown in figure 1. Fixed up method of transducers is shown as figure 2.

The steel stick is divided into 10 parts by steel bars. Every pull stick out 10 centimeters, bars can be put onto top cover of pipe and keep stick steady. Electronic on multi meter is steadier than handle it.

Transducer output analog signal, pressure need to be calculated. The distance between transducers is 30 centimeter.



Figure 1. Test equipment for lab test **Figure 2.** Transducers arrangement

3. Test method

3.1. Test design for density factor

3.1.1. *Test design.* Three materials was made. They are concrete, mortar and slurry. Keep pouring velocity, temperature and slumps constant. Just change materials. Detect pressure along pipe. Test design is shown as table 1.

Table 1. Test parameter for density changing test

Density / kg/m ³	Depth / m	Velocity / L/min	Temperature / °C	Slumps / mm
concrete	1.2	37.68	8	200
mortar	1.2	37.68	8	200
slurry	1.2	37.68	8	200

3.1.2. *Test steps.* 45L materials were ready for pouring. Fill pipe with a bucket. Keep pouring continuously. Take 1 minute to tank up the pipe. Keep steady for 5 seconds. Read the electric current value by multi meter. And then pull out stick 10 centimeters by 10 centimeters. Every 10 centimeters, read the electric current value until transducer on the bottom of stick is pull out of pipe.

3.2. Test design for pouring velocity factor

3.2.1. *Test design.* Design two pouring velocities. They are 5L/min and 10L/min. Keep density, temperature and slumps constant. Just change velocity. Detect pressure along pipe. Test design is shown as table 2.

Table 2. Test parameter for density changing test

Density / kg/m ³	Depth / m	Velocity / L/min	Temperature / °C	Slumps / mm
2300	1.2	5	8	200
2300	1.2	10	8	200

3.2.2. *Test steps.* 45L concrete was ready for pouring. Fill pipe with a 5L bucket. Take 1 minute for pouring 1 bucket. Keep pouring continuously until the pipe was full. We think this pouring velocity is 5L/min. Read the electric current value when there is display on the multi meter. For velocity of 10 L/min, use 10L bucket to pour the pipe.

3.3. Test design for temperature factor

3.3.1. *Test design.* Design two temperatures of concrete. They are 8 °C and 10 °C. Keep density, pouring velocity and slumps constant. Just change temperature of concrete. Detect pressure along pipe. Test design is shown as table 3.

Table 3. Test parameter for density changing test

Density / kg/m ³	Depth / m	Velocity / L/min	Temperature / °C	Slumps / mm
2300	1.2	37.68	8	200
2300	1.2	37.68	22	200

3.3.2. *Test steps.* water with different temperature were used. The water from tap water pipe is 8 °C. For 22 °C pouring temperature, mixing hot water and tap water for producing concrete is ok. Take 1 minute to fill pipe full with different temperature concretes respectively. Keep steady for 5 seconds. Read the electric current value by multi meter. And then pull out stick 10 centimeters by 10 centimeters. Every 10 centimeters, read the electric current value until transducer on the bottom of stick is pull out of pipe.

3.4. Test design for temperature factor

3.4.1. *Test design.* Design two level slumps. They are 300mm and 450mm. Keep density, pouring velocity and temperature constant. Just change slump of concrete. Detect pressure along pipe. Test design is shown as table 4.

Table 4. Test parameter for density changing test

Density / kg/m ³	Depth / m	Velocity / L/min	Temperature / °C	Slumps / mm
2300	1.2	37.68	8	300
2300	1.2	37.68	22	450

3.4.2. *Test steps.* 45L concrete was ready. The slump is changed by adding water reducing agent. Fill pipe with a bucket. Keep pouring continuously. Take 1 minute to tank up the pipe. Keep steady for 5 seconds. Read the electric current value by multi meter. And then pull out stick 10 centimeters by 10 centimeters. Every 10 centimeters, read the electric current value until transducer on the bottom of stick is pull out of pipe.

4. Results

4.1. Pressure changes by different materials

Figure 3 to figure 6 are about pressure along pipe for different density materials.




Figure 3. Pressure along pipe for concrete




Figure 4. Pressure along pipe for mortar




Figure 5. Pressure along pipe for slurry




Figure 6. Differential pressure for different materials

The same change rule of pressure on pipe is shown by Concrete, mortar and slurry. Pressure from transducers decrease by pulling out the stick. At the same mark position, the heavier density is, the higher pressure is. From differential pressure figure, at point 8, the upper transducer is pull out of materials into air. At point 12, the bottom transducer is also pull out of materials into air. The interface of concrete and air is the 8 position.

4.2. Pressure changes by pouring velocity

Figure 7 to figure 8 are about pressure along pipe for different pouring velocity.

At the same depth, the more quick pouring velocity is, the higher press is. This is because more quick pouring velocity lead to liquid level of concrete higher. The higher of concrete is, the more pressure is. For the same material, although pouring velocity is different, differential pressure is the same.

4.3. Pressure changes by temperature

Figure 9 and figure 10 are about pressure along pipe for different temperature.




Figure 7. Pressure for 5L/min pouring velocity




Figure 8. Pressure for 10L/min pouring velocity




Figure 9. Pressure for 8 °C temperature





Figure 10. Pressure for 22 °C temperature

For 8 °C and 22 °C concrete temperature, at the same depth, for example mark position 3, pressure are almost the same value. Differential pressure keeps constant no matter in 8 °C or 22 °C temperature. Therefore, concrete temperature is not affect to pressure along pipe. From differential pressure curve, interface of concrete and air can be found and that is point 8.

4.4. Pressure changed by slumps

Figure 11 and figure 12 are about pressure along pipe for different concrete slumps.



At the same depth, pressure from high slump concrete is less than that from low slump concrete. But the gap is not outstanding. Slump is not the main reason to lead to pipe pressure rising. From differential pressure curve, interface of concrete and air can be found and that is point 8.

5. Conclusions

In order to detect pressure change around pipe and find out the reasons leading to pipe pressure changed, some factors such as density, pouring velocity, concrete temperature and concrete slump must be considered. By means of simulate cast-in place pile construction in library, pressure along pipe were detected.

By changing materials, it can be seen that there should be a positive correlation between the density and the hydrodynamic pressure. By changing pouring velocity, it can be seen that there should be a positive correlation between pouring velocity and the hydrodynamic press. By changing concrete temperature, it can be seen that concrete temperature is not effect to pressure along pipe. By changing concrete slump with water reducing agent, the pressure gap between high slump and low one is not outstanding. The inducements of pipe pressure changing are not the concrete temperature and slump, but the density and velocity.

Acknowledgment

This work was supported by the Ministry of Communications and Enterprise Innovation Item [grant numbers 2015 315 Q13 040].

References

- [1] Zhang G Q, Yu L and Liu Z L 2017 Pouring simulation of cast-in place pile construction *Journal of Highway Communication technology* **2** 150-152
- [2] Zhang Z M 2007 Pile foundation project Beijing: China Building Industry Press 10-25
- [3] 2008 Technical code for safety of forms in construction JGJ 162-2008 Beijing: China building industry press
- [4] Yu L, Fu Y Y, Zhang J et al 2016 Test and simulation on pull-out behavior of steelwire in foam concrete, *Journal of Harbin Institute of Technology* **48** 6 119-123
- [5] Yuan S W 2014 Numerical simulation and experimental study of power-law fluid *East China University Of Science and Technology*